



WT: 6#(2.73KG)

PART No. :510-030

NOTE: ALL DIMENSIONS IN INCHES (MM)

MODEL 201 JB Box Overall Dimensions



www.wagnerengineering.ca

Wagner Engineering Ltd.
 135 Riverside Dr.
 North Vancouver, BC
 Canada V7H 1T8
 Tel. (604) 988-1111
 Fax (604) 988-0334

DATE	DWG No.	REV.
JUL 80	A-159	03
DRAWN		
MSE		